




# ETB1-63 Instruction Manual




**WARNING:**  
Products should only be installed by qualified  
technicians with electrical experience


## 1. Install the MCB onto the DIN-rail




## 2. Wiring diagram




## 3. Connecting the load line



## 4. Connecting the power line



## 5. Status Indicator



## 6. Disassembly: Take out the load line and power line, then remove the MCB from the DIN-rail

