




ETB1LME-40 Instruction Manual




WARNING:

Products should only be installed by qualified technicians with electrical experience


1. Install the RCBO onto the DIN-rail




2. Wiring diagram




3. Connecting the load line



4. Connecting the power line



5. Status Indicator



6. Disassembly: Take out the load line and power line, then remove the RCBO from the DIN-rail

